




# ŠKODA KODIAQ, KODIAQ RS (2016 - 2021)



For RS only

Legend

	Airbag		Stored gas inflator		Seat belt pretensioner		SRS control unit		Pedestrian protection active system
	Automatic rollover protection system		Gas strut / Preloaded spring		High strength zone		Zone requiring special attention		
	Battery low voltage		Ultra capacitor, low voltage		Fuel tank		Gas tank		Safety valve
	High voltage battery pack		High voltage power cable		High voltage device that disconnects high voltage		Fuse box disabling high voltage		High voltage ultra-capacitor
	Fuel tank content gasoline/ethanol		Fuel tank content Diesel						



**1. Identification / recognition**

Lettering **KODIAQ** on the tailgate.

RS from 2018




**2. Immobilisation / stabilisation / lifting**


**2A - Immobilisation / stabilisation**



**Automatic gearbox**  
 1. Shift selector lever into position "P".  
 2. Secure the vehicle with the parking brake.



**Manual gearbox**  
 1. Put the shift lever into neutral position.  
 2. Secure the vehicle with the parking brake.




Turn the ignition key to the "OFF position" and remove it

or





Press the START-STOP button.



Remove the key from the vehicle.

**2B - Lifting**

**Lifting points**



**3. Disable direct hazards / safety regulations**

**3A - Shut power off**




See chapter 2A



a) Locate the 12V battery, see chapter 3B.



b) Disconnect the 12V battery from the vehicle electrical system using a suitable tool.



or






1. Disconnect the negative pole (-).  
 2. Disconnect the positive pole (+).






3B - Access to 12V battery - Engine compartment




3B - Access to 12V battery - Luggage compartment (Kodiaq RS)




4. Access to the occupants

High strength body areas



Glass types: 1. Laminated safety glass  
2. Toughened safety glass



5. Stored energy / liquids / gases / solids

		63L
		63L
		12V
		0,5Kg

6. In case of fire



Use appropriate protective equipment!

ID-Number	Version number	Version date	Page
TMB- NS	05	12/2021	3 of 4



**7. In case of submersion**

After withdrawing the vehicle from the water, allow the water to drain.  
Use appropriate protective equipment!

**8. Towing / transportation / storage**

Do not tow the vehicle on the front axles.



**10. Explanation of pictograms used**

	Flammable		Environmental hazard		Corrosives
	Hazardous to the human health		Explosive		Vehicle on fuel of liquid group 2
	Air-conditioning component		General warning sign		Vehicle on fuel of liquid group 1
	Use water to extinguish the fire		Bonnet		Remove smart key
	Lifting point; central support		Boot		